# Virtuoso 700 CYC IP RGBALC

**User Manual** 



Order code: ELUM137



### WARNING

# FOR YOUR OWN SAFETY, PLEASE READ THIS USER MANUAL CAREFULLY BEFORE YOUR INITIAL START-UP!

- · Before your initial start-up, please make sure that there is no damage caused during transportation.
- Should there be any damage, consult your dealer and do not use the equipment.
- To maintain the equipment in good working condition and to ensure safe operation, it is necessary for the user to follow the safety instructions and warning notes written in this manual.
- · Please note that damages caused by user modifications to this equipment are not subject to warranty.



CAUTION!
KEEP THIS EQUIPMENT
AWAY FROM RAIN,
MOISTURE AND LIQUIDS



CAUTION! TAKE CARE USING THIS EQUIPMENT! HIGH VOLTAGE-RISK OF ELECTRIC SHOCK!!

#### **IMPORTANT:**

The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorised modification to the equipment.

- Never let the power cable come into contact with other cables.
   Handle the power cable and all mains voltage connections with particular caution!
- Never remove warning or informative labels from the unit.
- Do not open the equipment and do not modify the unit.
- Do not connect this equipment to a dimmer pack.
- Do not switch the equipment on and off in short intervals, as this will reduce the system's life.
- · Only use the equipment indoors.
- Do not expose to flammable sources, liquids or gases.
- Always disconnect the power from the mains when equipment is not in use or before cleaning! Only handle the power-cable by the plug. Never pull out the plug by pulling the power-cable.
- Make sure that the available mains supply voltage is between 100~240V AC, 50/60Hz.
- Make sure that the power cable is never crimped or damaged. Check the equipment and the power cable periodically.
- If the equipment has been exposed to drastic temperature fluctuation (e.g. after transportation), do not connect power or switch it on immediately.
   The arising condensation might damage the equipment.
   Leave the equipment switched off until it has reached room temperature.

- · Never touch the fixture during operation as it may be hot.
- If the equipment is dropped or damaged, disconnect the mains power supply immediately and have a qualified engineer inspect the equipment before operating again.
- If your product fails to function correctly, stop use immediately.
   Pack the unit securely (preferably in the original packing material), and return it to your Pro Light dealer for service.
- · Only use fuses of same type and rating.
- Repairs, servicing and power connection must only be carried out by a qualified technician. THIS UNIT CONTAINS NO USER SERVICEABLE PARTS.
- This lighting fixture is for professional use only it is not designed
  for or suitable for household use. The product must be installed
  by a qualified technician in accordance with local territory
  regulations. The safety of the installation is the responsibility of
  the installer. The fixture presents risks of severe injury or death
  due to fire hazards, electric shock and falls.
- Warning! Risk Group 2 LED product according to EN 62471. Do not view the light output with optical instruments or any device that may concentrate the beam.
- · WARRANTY: Two years from date of purchase.

#### **OPERATING DETERMINATIONS**

If this equipment is operated in any other way, than those described in this manual, the product may suffer damage and the warranty becomes void. Incorrect operation may lead to danger e.g. short-circuit, burns and electric shocks etc.

Do not endanger your own safety and the safety of others!

Incorrect installation or use can cause serious damage to people and/or property.

**Please note:** These fixtures are intended for stage lighting and entertainment applications only, and are not intended for extended periods of use, including but not limited to house-light, industrial or architectural applications and should only be operated with short duty cycles.

### Virtuoso 700 CYC IP RGBALC

The Virtuoso 700 CYC IP is an IP65 rated CYC/footlight designed for film, theatre, and TV productions. With its high CRI and homogenous output, it delivers exceptional colour accuracy and even illumination. Equipped with a powerful 180W RGBALC LED, it offers a wide range of vibrant colours. One of its standout features is the safety light function, which keeps the LEDs on at a low level during 'blackouts' to highlight the stage's edge and prevent accidents. The adjustable foot ensures easy positioning, whilst the included eyebrow allows for precise beam adjustment. Additionally, the Virtuoso 700 CYC IP operates silently and boasts an IP65 rating for dust and water resistance. Its HSIC/CMY colour management system enables the creation of virtually any colour, while the virtual colour wheel provides quick access to a multitude of hues. Furthermore, it offers colour temperature control from 1800K to 10000K. What more could you ask for from such a feature-packed fixture.


- 2 year warranty
- 1 x 180W six-colour LED Array (RGBALC)
- Beam angle: 70°
- 1,425 Lux @ 2m
- CRI: 93
- Colour temperature: 1800K-10000K
- Refresh rate: 1.2kHz, 2.4kHz, 4kHz, 6kHz or 25kHz selectable
- · Eyebrow for beam shaping
- DMX channels: 3/7/8/10/13/ or 20 selectable
- RDM (Remote Device Management)
- · Safety light feature
- · Auto and master/slave modes
- 48 preset colour macros
- 0 100% 8 or 16 bit dimming
- · Variable strobe
- Adjustable central foot
- Quick release omega clamp included
- 4 button menu with OLED display
- PowerCON TRUE1 input/output
- IP rated 5-Pin XLR inputs/outputs
- · Convection cooled


| Specifications    | Virtuoso 700 CYC IP RGBALC |
|-------------------|----------------------------|
| Power consumption | 180W                       |
| Power supply      | 100~240V, 50/60Hz          |
| IP rating         | IP65                       |
| Fuse              | T2A 250V                   |
| Dimensions        | 120 x 530 x 170mm          |
| Weight            | 6kg                        |
| Order code        | ELUM137                    |



| 70° - Lux      |      |      |     |     |     |
|----------------|------|------|-----|-----|-----|
| <b>FULL ON</b> | 5700 | 1425 | 634 | 356 | 228 |
| R              | 644  | 161  | 72  | 40  | 26  |
| G              | 1052 | 263  | 119 | 66  | 42  |
| В              | 196  | 49   | 22  | 12  | 8   |
| Α              | 1000 | 250  | 111 | 63  | 40  |
| L              | 2124 | 531  | 236 | 133 | 85  |
| С              | 412  | 103  | 46  | 26  | 17  |







01 - OLED display

02 - Function buttons

05 - Eyebrow

03 - PowerCON TRUE1 output

04 - 5-Pin DMX output

06 - 5-Pin DMX input

07 - PowerCON TRUE1 input

08 - Central foot

09 - Omega mounting points

In the box: 1 x fixture,

1 x eyebrow,

1 x omega clamp


1 x safety wire

& 1 x power cable



Before installing the fixture, the supporting structure (ie. truss) must be able to hold a minimum of 10 times the fixtures weight without any deformation (eg. 15kg - 150kg point load). The fixture must be secured with a secondary safety attachment when being installed (ie. an appropriate safety cable). Never stand directly below the fixture when mounting, removing, and/or servicing.


Overhead installation requires experience and qualifications to calculate working load limits, the material being used at the installation area and periodic safety inspections of the fixture and installation material. If you do not have the relevant experience and/or qualifications please do not attempt the installation yourself. The installation should be checked annually by a qualified person.



The Elumen8 Virtuoso 700 CYC IP RGBALC can be operated in a number of mounting positions as shown in the diagram above, hanging upside-down from the ceiling or truss, mounting sideways on truss or stood upright on a flat level surface. Always use a safety wire as an extra safety precaution to prevent damage/injury in the event a clamp fails (see the next page for clamp installation). Never use the carry handles for secondary attachments.

### **Installation:**

- 1. Fasten the clamp to the fixtures bracket with a bolt and lock nut through one of the mounting holes.
- 2. Mount the fixture onto your truss system via the clamp and tighten to ensure secure.
- 3. Pull the safety cable through the fixture safety eye and around the truss.



| Main Menu   | Sub Menus      |                         |        | Values (Default<br>Settings in BOLD) | Description                            |
|-------------|----------------|-------------------------|--------|--------------------------------------|--|
|             | RED            |                         |        | 000-255                              |  |
|             | GREEN          |                         |        | 000-255                              |  |
|             | BLUE           |                         |        | 000-255                              | Manual mode                            |
| STATIC      | AMBER          |                         |        | 000-255                              |  |
|             | LIME           |                         |        | 000-255                              |  |
|             | CYAN           |                         |        | 000-255                              |  |
|             | STROBE         |                         |        | 000-25                               |  |
| ADDRESS     |                |                         |        | <b>001</b> -512                      | DMX address settings                   |
| DUN MODE    |                |                         |        | DMX                                  | Dun made estima                        |
| RUN MODE    |                |                         |        | Slave                                | Run mode settings                      |
|             |                |                         |        | Basic                                |  |
|             |                |                         |        | SSP                                  |  |
| DEDOONALIE  | ,              |                         |        | Tour                                 | DMX channel mode                       |
| PERSONALITY | Y              |                         |        | TR16                                 | settings                               |
|             |                |                         |        | HSIC                                 |  |
|             |                |                         |        | CMY                                  |  |
|             | AUTO 1         |                         |        | 000-255                              |  |
|             | AUTO 2         |                         |        | 000-255                              |  |
|             | AUTO 3         |                         |        | 000-255                              | - Auto/custom programs                 |
|             | AUTO 4         |                         |        | 000-255                              |  |
|             | AUTO 5         |                         |        | 000-255                              |  |
| AUTO        | AUTO 6         |                         |        | 000-255                              |  |
| PROGRAM     | AUTO 7         |                         |        | 000-255                              |  |
|             | AUTO 8         |                         |        | 000-255                              |  |
|             | AUTO 9         |                         |        | 000-255                              |  |
|             | AUTO 10        |                         |        | 000-255                              |  |
|             | PR 1           |                         |        | ^                                    | 1                                      |
|             | PR 2           |                         |        | ,                                    |  |
|             |                |                         | RED    | 000-255                              |  |
|             |                |                         | GREEN  | 000-255                              |  |
|             |                |                         | BLUE   | 000-255                              |  |
|             |                |                         | AMBER  | 000-255                              |  |
|             | PROGRAM<br>1-2 | SCENE<br>1-10           | LIME   | 000-255                              | Custom program settings                |
|             | 1-2            | 1-10                    | CYAN   | 000-255                              |  |
| EDIT        |                |                         | STROBE | 000-25                               |  |
|             |                |                         | TIME   | 000-255                              |  |
|             |                |                         | FADE   | 000-255                              | ]                                      |
|             | UPLOAD         | PASSCODE (SUP) S COOWNS |        |                                      | Send custom programs to slave fixtures |

| Main Menu | Sub Menus                                   |           |  | Values (Default<br>Settings in BOLD)            | Description  |
|-----------|---|-----------|--|---|--|
|           |   |           | PASSCODE ( <up>, <do'<br><down>, <enter>)</enter></down></do'<br></up> |   | Restore factory settings   |
|           |   | DIMMER    |  | DIM4 OFF  | Dimmer settings  |
|           |   | DMX ERROR |  | SAVE<br>BLACK                                   | DMX fail settings  |
|           | PASSCODE                                    |           |  | 1200Hz  |  |
| SETTING   | ( <up><br/><down><br/><up></up></down></up> | PWM RATE  |  | 2400Hz<br>4000Hz                                | Refresh rate settings  |
| SETTING   | <down><br/><enter>)</enter></down>          |           |  | 6000Hz<br>25000Hz                               |  |
|           |   | DISP KEY  |  | ON  | Display lock setting (passcode is <up>, <down>,<up>, <down>,</down></up></down></up> |
|           |   |           |  | OFF   | <enter>)</enter>   |
|           |   | DISP TIME |  | 10S   | Display backlight settings   |
|           |   |           |  | 30S<br>2MIN                                     |  |
|           | FIXTURE HO                                  | URS       |  | xxh   | Fixture hours  |
|           | VERSION                                     | T         |  | VXXXXXXXX                                       | Software version   |
| INFO      | RDM   | LABEL     |  | 0X09a5XXXXXXXX<br>VIRTUOSO 700<br>CYC IP RGBALC | Fixture UID Fixture model  |
|           | 1800K                                       |           |  |   |  |
|           | 2200K                                       |           |  |   |  |
|           | 2700K                                       |           |  |   |  |
|           | 3000K                                       |           |  |   | _  |
|           | 3200K                                       |           |  |   |  |
|           | 4000K                                       | 4000K     |  |   | _  |
| CCT       | 4500K                                       |           |  | Colour temperature                              |  |
|           | 5000K                                       |           |  | presets   |  |
|           | 5600K                                       |           |  | ]   |  |
|           | 6000K                                       |           |  | ]   |  |
|           | 6500K                                       |           |  |   |  |
|           | 7000K                                       |           |  | _   |  |
|           | 8000K                                       |           |  |   | _  |
|           | 10000K                                      |           |  |   |  |



### **DMX channel modes:**

### 3 channel mode (BASIC):

| Channel | Value       | Function                    |
|---------|-------------|-----------------------------|
| CH1     | 000-255     | Master dimmer (0-100%)      |
|         | Colour pres | ets                         |
| CH2     | 000-010     | No function                 |
|         | 011-255     | Preset colour (pages 15-16) |
|         | Colour tem  | perature presets            |
|         | 000-009     | No function                 |
|         | 009-010     | 1800K                       |
|         | 000-025     | 2200K                       |
|         | 026-040     | 2700K                       |
|         | 041-055     | 3000K                       |
|         | 056-070     | 3200K                       |
| CH3     | 071-085     | 4000K                       |
| СПЗ     | 086-100     | 4500K                       |
|         | 101-115     | 5000K                       |
|         | 116-130     | 5600K                       |
|         | 131-145     | 6000K                       |
|         | 146-160     | 6500K                       |
|         | 161-175     | 7000K                       |
|         | 176-190     | 8000K                       |
|         | 191-255     | 10000K                      |

### 7 channel mode (HSIC):

| Channel     | Value   | Function                     |
|-------------|---------|------------------------------|
| CH1         | 000-255 | Intensity (0-100%)           |
| CH2         | 000-255 | Hue                          |
| CH3         | 000-255 | Hue fine                     |
| CH4         | 000-255 | Saturation                   |
|             |         | perature presets             |
|             | 000-009 | No function                  |
|             | 009-010 | 1800K                        |
|             | 011-025 | 2200K                        |
|             | 026-040 | 2700K                        |
|             | 041-055 | 3000K                        |
|             | 056-070 | 3200K                        |
|             | 071-085 | 4000K                        |
| CH5         | 086-100 | 4500K                        |
|             | 101-115 | 5000K                        |
|             | 116-130 | 5600K                        |
|             | 131-145 | 6000K                        |
|             | 146-160 | 6500K                        |
|             | 161-175 | 7000K                        |
|             | 176-190 | 8000K                        |
|             | 191-255 | 10000K                       |
|             | Strobe  |                              |
|             | 000-009 | No function                  |
|             | 010-099 | Strobe (slow-fast)           |
| сн6         | 100-109 | No function                  |
|             | 110-179 | Lightning strobe (slow-fast) |
|             | 180-189 | No function                  |
|             | 190-255 | Random strobe (slow-fast)    |
|             | Control |                              |
|             | 000-100 | No function                  |
|             | 101-110 | Dimmer Off                   |
|             | 111-120 | Dimmer Dim4                  |
|             | 121-150 | No function                  |
| CH7         | 151-160 | 1200Hz                       |
| OΠ <i>I</i> | 161-170 | 2400Hz                       |
|             | 171-180 | 4000Hz                       |
|             | 181-190 | 6000Hz                       |
|             | 191-200 | 25000Hz                      |
|             | 201-210 | All reset                    |
|             | 211-255 | No function                  |

### 8 channel mode (SSP):

| Channel | Value   | Function                     |
|---------|---------|------------------------------|
| CH1     | 000-255 | Master dimmer (0-100%)       |
| CH2     | 000-255 | Red dimmer (0-100%)          |
| CH3     | 000-255 | Green dimmer (0-100%)        |
| CH4     | 000-255 | Blue dimmer (0-100%)         |
| CH5     | 000-255 | Amber dimmer (0-100%)        |
| CH6     | 000-255 | Lime dimmer (0-100%)         |
| CH7     | 000-255 | Cyan dimmer (0-100%)         |
|         | Strobe  |                              |
|         | 000-009 | No function                  |
|         | 010-099 | Strobe (slow-fast)           |
| CH8     | 100-109 | No function                  |
|         | 110-179 | Lightning strobe (slow-fast) |
|         | 180-189 | No function                  |
|         | 190-255 | Random strobe (slow-fast)    |

### 10 channel mode (CMY):

| Channel | Value       | Function                          |
|---------|-------------|-----------------------------------|
| CH1     | 000-255     | Master dimmer (0-100%)            |
| CH2     | 000-255     | Cyan dimmer (0-100%)              |
| СНЗ     | 000-255     | Magenta dimmer (0-100%)           |
| CH4     | 000-255     | Yellow dimmer (0-100%)            |
|         | Colour pres | ets                               |
| CH5     | 000-010     | No function                       |
|         | 011-255     | Preset colour (pages 15-16)       |
|         | Colour tem  | perature presets                  |
|         | 000-009     | No function                       |
|         | 009-010     | 1800K                             |
|         | 011-025     | 2200K                             |
|         | 026-040     | 2700K                             |
|         | 041-055     | 3000K                             |
|         | 056-070     | 3200K                             |
| CH6     | 071-085     | 4000K                             |
| CHO     | 086-100     | 4500K                             |
|         | 101-115     | 5000K                             |
|         | 116-130     | 5600K                             |
|         | 131-145     | 6000K                             |
|         | 146-160     | 6500K                             |
|         | 161-175     | 7000K                             |
|         | 176-190     | 8000K                             |
|         | 191-255     | 10000K                            |
|         | Auto        |                                   |
|         | 000-040     | No function                       |
|         | 041-050     | Auto 1                            |
|         | 051-060     | Auto 2                            |
|         | 061-070     | Auto 3                            |
|         | 071-080     | Auto 4                            |
|         | 081-090     | Auto 5                            |
| CH7     | 091-100     | Auto 6                            |
|         | 101-110     | Auto 7                            |
|         | 111-120     | Auto 8                            |
|         | 121-130     | Auto 9                            |
|         | 131-140     | Auto 10                           |
|         | 141-150     | Custom 1                          |
|         | 151-160     | Custom 2                          |
|         | 161-255     | No function                       |
| CH8     | 000-255     | Auto speed adjustment (slow-fast) |

| Channel | Value   | Function                     |
|---------|---------|------------------------------|
|         | Strobe  |                              |
|         | 000-009 | No function                  |
|         | 010-099 | Strobe (slow-fast)           |
| СН9     | 100-109 | No function                  |
|         | 110-179 | Lightning strobe (slow-fast) |
|         | 180-189 | No function                  |
|         | 190-255 | Random strobe (slow-fast)    |
|         | Control |                              |
|         | 000-100 | No function                  |
|         | 101-110 | Dimmer Off                   |
|         | 111-120 | Dimmer Dim4                  |
|         | 121-150 | No function                  |
| CH10    | 151-160 | 1200Hz                       |
| CITE    | 161-170 | 2400Hz                       |
|         | 171-180 | 4000Hz                       |
|         | 181-190 | 6000Hz                       |
|         | 191-200 | 25000Hz                      |
|         | 201-210 | All reset                    |
|         | 211-255 | No function                  |

### 13 channel mode (TOUR):

| Channel | Value       | Function                    |
|---------|-------------|-----------------------------|
| CH1     | 000-255     | Master dimmer (0-100%)      |
| CH2     | 000-255     | Red dimmer (0-100%)         |
| СНЗ     | 000-255     | Green dimmer (0-100%)       |
| CH4     | 000-255     | Blue dimmer (0-100%)        |
| CH5     | 000-255     | Amber dimmer (0-100%)       |
| CH6     | 000-255     | Lime dimmer (0-100%)        |
| CH7     | 000-255     | Cyan dimmer (0-100%)        |
|         | Colour pres | ets                         |
| CH8     | 000-010     | No function                 |
|         | 011-255     | Preset colour (pages 15-16) |
|         | Colour tem  | perature presets            |
|         | 000-009     | No function                 |
|         | 009-010     | 1800K                       |
|         | 000-025     | 2200K                       |
|         | 026-040     | 2700K                       |
|         | 041-055     | 3000К                       |
|         | 056-070     | 3200K                       |
| CHO     | 071-085     | 4000K                       |
| CH9     | 086-100     | 4500K                       |
|         | 101-115     | 5000K                       |
|         | 116-130     | 5600K                       |
|         | 131-145     | 6000K                       |
|         | 146-160     | 6500K                       |
|         | 161-175     | 7000K                       |
|         | 176-190     | 8000K                       |
|         | 191-255     | 10000K                      |
|         | Auto        |                             |
|         | 000-040     | No function                 |
|         | 041-050     | Auto 1                      |
|         | 051-060     | Auto 2                      |
|         | 061-070     | Auto 3                      |
|         | 071-080     | Auto 4                      |
| CH10    | 081-090     | Auto 5                      |
|         | 091-100     | Auto 6                      |
|         | 101-110     | Auto 7                      |
|         | 111-120     | Auto 8                      |
|         | 121-130     | Auto 9                      |
|         | 131-140     | Auto 10                     |
|         | 141-150     | Custom 1                    |

| Channel | Value   | Function                          |
|---------|---------|-----------------------------------|
| CH10    | 151-160 | Custom 2                          |
| (cont.) | 161-255 | No function                       |
| CH11    | 000-255 | Auto speed adjustment (slow-fast) |
|         | Control |                                   |
|         | 000-009 | No function                       |
|         | 010-099 | Strobe (slow-fast)                |
| CH12    | 100-109 | No function                       |
|         | 110-179 | Lightning strobe (slow-fast)      |
|         | 180-189 | No function                       |
|         | 190-255 | Random strobe (slow-fast)         |
|         | 000-100 | No function                       |
|         | 101-110 | Dimmer Off                        |
|         | 111-120 | Dimmer Dim4                       |
|         | 121-150 | No function                       |
|         | 151-160 | 1200Hz                            |
| CH13    | 161-170 | 2400Hz                            |
|         | 171-180 | 4000Hz                            |
|         | 181-190 | 6000Hz                            |
|         | 191-200 | 25000Hz                           |
|         | 201-210 | All reset                         |
|         | 211-255 | No function                       |

### 20 channel mode (TR16):

| Channel | Value       | Function                    |
|---------|-------------|-----------------------------|
| CH1     | 000-255     | Master dimmer (0-100%)      |
| CH2     | 000-255     | Master dimmer Fine          |
| CH3     | 000-255     | Red dimmer (0-100%)         |
| CH4     | 000-255     | Red Fine                    |
| CH5     | 000-255     | Green dimmer (0-100%)       |
| CH6     | 000-255     | Green Fine                  |
| CH7     | 000-255     | Blue dimmer (0-100%)        |
| CH8     | 000-255     | Blue Fine                   |
| CH9     | 000-255     | Amber dimmer (0-100%)       |
| CH10    | 000-255     | Amber Fine                  |
| CH11    | 000-255     | Lime dimmer (0-100%)        |
| CH12    | 000-255     | Lime Fine                   |
| CH13    | 000-255     | Cyan dimmer (0-100%)        |
| CH14    | 000-255     | Cyan Fine                   |
|         | Colour pres | ets                         |
| CH15    | 000-010     | No function                 |
|         | 011-255     | Preset colour (pages 15-16) |
|         | Colour tem  | perature presets            |
|         | 000-009     | No function                 |
|         | 009-010     | 1800K                       |
|         | 011-025     | 2200K                       |
|         | 024-040     | 2700K                       |
|         | 039-055     | 3000K                       |
|         | 056-070     | 3200K                       |
| CH16    | 071-085     | 4000K                       |
| CUTO    | 086-100     | 4500K                       |
|         | 101-115     | 5000K                       |
|         | 116-130     | 5600K                       |
|         | 131-145     | 6000K                       |
|         | 146-160     | 6500K                       |
|         | 161-175     | 7000K                       |
|         | 176-190     | 8000K                       |
|         | 191-255     | 10000K                      |

| Channel | Value   | Function                          |  |
|---------|---------|-----------------------------------|--|
|         | Auto    |                                   |  |
|         | 000-040 | No function                       |  |
|         | 041-050 | Auto 1                            |  |
|         | 051-060 | Auto 2                            |  |
|         | 061-070 | Auto 3                            |  |
|         | 071-080 | Auto 4                            |  |
|         | 081-090 | Auto 5                            |  |
| CH17    | 091-100 | Auto 6                            |  |
|         | 101-110 | Auto 7                            |  |
|         | 111-120 | Auto 8                            |  |
|         | 121-130 | Auto 9                            |  |
|         | 131-140 | Auto 10                           |  |
|         | 141-150 | Custom 1                          |  |
|         | 151-160 | Custom 2                          |  |
|         | 161-255 | No function                       |  |
| CH18    | 000-255 | Auto speed adjustment (slow-fast) |  |
|         | Strobe  |                                   |  |
|         | 000-009 | No function                       |  |
|         | 010-099 | Strobe (slow-fast)                |  |
| CH19    | 100-109 | No function                       |  |
|         | 110-179 | Lightning strobe (slow-fast)      |  |
|         | 180-189 | No function                       |  |
|         | 190-255 | Random strobe (slow-fast)         |  |
|         | Control |                                   |  |
| CH20    | 000-100 | No function                       |  |
|         | 101-110 | Dimmer Off                        |  |
|         | 111-120 | Dimmer Dim4                       |  |
|         | 121-150 | No function                       |  |
|         | 151-160 | 1200Hz                            |  |
|         | 161-170 | 2400Hz                            |  |
|         | 171-180 | 4000Hz                            |  |
|         | 181-190 | 6000Hz                            |  |
|         | 191-200 | 25000Hz                           |  |
|         | 201-210 | All reset                         |  |
|         | 211-255 | No function                       |  |



|               | Description |             |                       | DMX Values |
|---------------|-------------|-------------|-----------------------|------------|
|               | Blackout    | No Function | Blackout              | 000-010    |
|               | Colour 1    | L176        | Loving Amber          | 011-015    |
|               | Colour 2    | R40         | Light Salmon          | 016-020    |
|               | Colour 3    | L24         | Scarlet               | 021-025    |
|               | Colour 4    | L164        | Flame Red             | 026-030    |
|               | Colour 5    | L747        | Easy White            | 031-035    |
|               | Colour 6    | R303        | Warm Peach            | 036-040    |
|               | Colour 7    | L08         | Dark Salmon           | 041-045    |
|               | Colour 8    | L25         | Sunset Red            | 046-050    |
|               | Colour 9    | L04         | Medium Bastard Amber  | 051-055    |
|               | Colour 10   | L237        | CID (To Tungsten)     | 056-060    |
|               | Colour 11   | R321        | Soft Golden Amber     | 061-065    |
|               | Colour 12   | L652        | Urban Sodium          | 066-070    |
|               | Colour 13   | L212        | LCT Yellow (Y1)       | 071-075    |
|               | Colour 14   | L765        | LEE Yellow            | 076-080    |
|               | Colour 15   | L513        | Ice And A Slice       | 081-085    |
|               | Colour 16   | L100        | Spring Yellow         | 086-090    |
|               | Colour 17   | L244        | LEE Plus Green        | 091-095    |
|               | Colour 18   | R4430       | CalColor 30 Green     | 096-100    |
| Preset Colour | Colour 19   | L122        | Fern Green            | 101-105    |
|               | Colour 20   | L90         | Dark Yellow Green     | 106-110    |
|               | Colour 21   | L243        | LEE Fluorescent 3600K | 111-115    |
|               | Colour 22   | R92         | Turquoise             | 116-120    |
|               | Colour 23   | R94         | Kelly Green           | 121-125    |
|               | Colour 24   | L327        | Forest Green          | 126-130    |
|               | Colour 25   | L191        | Cosmetic Aqua Blue    | 131-135    |
|               | Colour 26   | L728        | Steel Green           | 136-140    |
|               | Colour 27   | L117        | Steel Blue            | 141-145    |
|               | Colour 28   | L354        | Special Steel Blue    | 146-150    |
|               | Colour 29   | L53         | Paler Lavender        | 151-155    |
|               | Colour 30   | L501        | New Colour Blue       | 156-160    |
|               | Colour 31   | L174        | Dark Steel Blue       | 161-165    |
|               | Colour 32   | L165        | Daylight Blue         | 166-170    |
|               | Colour 33   | L136        | Pale Lavender         | 171-175    |
|               | Colour 34   | L194        | Surprise Pink         | 176-180    |
|               | Colour 35   | L142        | Pale Violet           | 181-185    |
|               | Colour 36   | L700        | Perfect Lavender      | 186-190    |
|               | Colour 37   | L35         | Light Pink            | 191-195    |
|               | Colour 38   | L794        | Pretty'n Pink         | 196-200    |
|               | Colour 39   | L328        | Follies Pink          | 201-205    |
|               |             | 1           |                       | 206-210    |
|               | Colour 40   | L795        | Magical Magenta       | ZU0-ZTU    |

|                          | Description |             |                      | DMX Values |
|--------------------------|-------------|-------------|----------------------|------------|
| Preset colour<br>(cont.) | Colour 41   | L154        | Pale Rose            | 211-215    |
|                          | Colour 42   | L127        | Smokey Pink          | 216-220    |
|                          | Colour 43   | L192        | Flesh Pink           | 221-225    |
|                          | Colour 44   | L332        | Special Rose Pink    | 226-230    |
|                          | Colour 45   | L790        | Moroccan Pink        | 231-235    |
|                          | Colour 46   | L157        | Pink                 | 236-240    |
|                          | Colour 47   | R332        | Cherry Rose          | 241-245    |
|                          | Colour 48   | L128        | Cool LED Bright Pink | 246-250    |
|                          | Blackout    | No Function | Blackout             | 251-255    |



#### Setting the DMX address:

The DMX mode enables the use of a universal DMX controller. Each fixture requires a "start address" from 1-512. A fixture requiring one or more channels for control begins to read the data on the channel indicated by the start address. For example, a fixture that occupies or uses 7 channels of DMX and was addressed to start on DMX channel 100, would read data from channels: 100, 101, 102, 103, 104, 105 and 106. Choose a start address so that the channels used do not overlap. E.g. the next unit in the chain starts at 107.

#### DMX 512:

DMX (Digital Multiplex) is a universal protocol used as a form of communication between intelligent fixtures and controllers. A DMX controller sends DMX data instructions form the controller to the fixture. DMX data is sent as serial data that travels from fixture to fixture via the DATA "IN" and DATA "OUT" XLR terminals located on all DMX fixtures (most controllers only have a data "out" terminal).

#### **DMX linking:**

DMX is a language allowing all makes and models of different manufactures to be linked together and operate from a single controller, as long as all fixtures and the controller are DMX compliant. To ensure proper DMX data transmission, when using several DMX fixtures try to use the shortest cable path possible. The order in which fixtures are connected in a DMX line does not influence the DMX addressing. For example; a fixture assigned to a DMX address of 1 may be placed anywhere in a DMX line, at the beginning, at the end, or anywhere in the middle. When a fixture is assigned a DMX address of 1, the DMX controller knows to send DATA assigned to address 1 to that unit, no matter where it is located in the DMX chain.

#### DATA cable (DMX cable) requirements (for DMX operation):

This fixture can be controlled via DMX-512 protocol. The DMX address is set on the back of the unit. Your unit requires either a standard 3-pin or 5-pin XLR connector for data input/output, see images below.



Further DMX cables can be purchased from all good sound and lighting suppliers or Prolight Concepts dealers.

Please quote: 3-Pin: CABL10 - 2m CABL11 - 5m CABL12 - 10m


5-Pin: CABL185 - 2m CABL187 - 5m CABL188 - 10m


Also remember that DMX cable must be daisy chained and cannot be split.

#### Notice:

Be sure to follow the diagrams below when making your own cables. Do not connect the cables shield conductor to the ground lug or allow the shield conductor to come in contact with the XLRs outer casing. Grounding the shield could cause a short circuit and erratic behaviour.

| Pin Configuration |             |  |  |  |
|-------------------|-------------|--|--|--|
| 3-Pin             | 5-Pin       |  |  |  |
| Pin 1 - Ground    |             |  |  |  |
| Pin 2 - Negative  |             |  |  |  |
| Pin 3 - Positive  |             |  |  |  |
| -                 | Pin 4 - N/C |  |  |  |
| _                 | Pin 5 - N/C |  |  |  |






#### **Line termination:**

When longer runs of cable are used, you may need to use a terminator on the last unit to avoid erratic behaviour.

Using a cable terminator will decrease the possibilities of erratic behaviour.

(3-pin - Order ref: CABL90, 5-pin - Order ref: CABL89)



#### 5-pin XLR DMX connectors:

Some manufactures use 5-pin XLR connectors for data transmission in place of 3-pin. 5-pin XLR fixtures may be implemented in a 3-pin XLR DMX line. When inserting standard 5-pin XLR connectors in to a 3-pin line a cable adaptor must be used. The diagram below details the correct cable conversion.






#### **Power linking:**

This fixture provides power linking via the power output on the rear allowing multiple units to be connected together. The maximum number of fixtures that can be connected is 8 fixtures @ 240V or 4 fixtures @ 120V (including the first fixture). After the maximum number of fixtures are connected a new power run will need to be started.

Please note: Caution should be used when power linking other fixtures to the Virtuoso 700 CYC IP RGBALC as the power consumption of other fixtures will vary. Fixtures fitted with lamps often require 2/3 times more current on startup, these may require their own power source.





# Correct Disposal of this Product (Waste Electrical & Electronic Equipment)

(Applicable in the European Union and other European countries with separate collection systems)

This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

