

B404BL

e-audio Bluetooth Ceiling Speaker Kit

IMPORTANT

Installer and Users please note:

These instructions should be read carefully and left with the user of the product for future reference.

BEFORE USE

You must inspect the product and its power supply for any signs of damage. If the product or power supply is damaged, DO NOT use it, and contact your supplier immediately.

PRODUCT SAFETY

- This unit can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the unit in a safe way and understand the hazards involved.
- · Children below 8 years shall not play with the unit.
- Do not use this unit in locations where paint, petrol or other flammable liquids or materials are used or stored.
- To prevent the risk of electric shock or fire do not expose the amplifier or power supply to moisture or rain.
- If the amplifier or power supply comes into contact with water or other liquids stop using immediately and have the unit checked by a qualified person before further use.
- · Ensure there is adequate ventilation around the unit and the power supply before use
- Do not use the unit for any purpose other than its intended use.
- Check the unit and power supply for damage periodically. If any damage is detected stop using it immediately and consult your supplier.
- For domestic use only
- · There are no user serviceable parts in this product
- Do not leave this product switched on unattended.
- Only use the power supply provided with this unit
- This unit and its components must only be installed by a competent person after taking a site survey to establish that the structure is suitable and that there are no existing plumbing, gas, electrical services or other obstructions already in place.
- · Disconnect from the mains supply when not in use.

GENERAL SAFETY REQUIREMENTS

Domestic wiring must be tested periodically by a qualified electrician at least once every 10 years or at every change of occupancy.

For office and retail premises, and buildings such as village halls, the wiring must be inspected at least once every 5 years.

It is recommended that all building be fitted with smoke alarms (it is mandatory for new buildings).

BOX CONTENTS

2 X Ceiling Speakers

- 2 x 3m speaker cables
- 1 x Bluetooth Power Amplifier

1 x Power Supply

1 x Ceiling Speaker Cut-Out Template

PLACEMENT


Locate the amplifier on a wall (using the tabs at either end for screws, see diagram on next page), in a cavity wall or in a ceiling.

The ceiling speakers can be fitted in a ceiling or cavity wall by a competent person after a site survey has been carried out to ensure there are no existing plumbing, gas or electrical services.

INSTALLATION AND CONNECTION

1. The ceiling speakers must be fitted by a competent person after a site survey has been carried out to ensure there are no existing plumbing, gas or electrical services. The provided cut-out template and appropriate tools should be used to install the speakers.

- 2. Attach the black cable (terminal end) to the terminal marked with a minus symbol (-) on the speaker.
- 3. Attach the red cable (terminal end) to the terminal marked with a plus symbol (+) on the speaker. This should be repeated for both speakers (A and B on the diagram below)
- 4. Remove the euro block terminal (as shown in diagram below)
- 5. Connect the cable (bare end) attached to speaker A, to the two left hand connections in the euro block (observing the polarity). The black cable should be on the left (labelled as 1 in the diagram below) and the red cable on the right (labelled as 2 on the diagram below)
- 6. Connect the cable (bare end) attached to speaker B, to the two right hand connections in the euro block (observing the polarity). The red cable should be on the right (labelled as 4 in the diagram below) and the black cable on the left (labelled as 3 on the diagram below)
- 7. Tighten the screws on the euro block using a suitable screwdriver.
- 8. Insert the power plug from the power supply into the socket on the amplifier (labelled as 5 on the diagram below)
- 9. Plug the power supply into a mains outlet and switch on.



DEVICE SYNCING

To connect the amplifier to your device;

- 1. Ensure that the Bluetooth function on your mobile device is set to 'ON'
- 2. Ensure that the amplifier is plugged in
- 3. The amplifier should now be discoverable by your mobile device (you may need to scan for new devices)

4. The amplifier will show as 'B404BL'. To sync select the device name and enter the password - 012345

PAT TESTING

When used in a workplace, this product must be safety-tested yearly by a qualified electrician (PAT Tested) in order to comply with the Electricity at Work Regulations.

If hired out, it must be PAT tested prior to each hire.

We recommend that it is PAT tested regularly when used in a domestic environment.

DISPOSAL AND RECYCLING

You must not dispose of this appliance with domestic household waste.

Most local authorities have specific collection system for appliances and disposal is free of charge to the end-user.

When replacing an existing appliance with a similar new appliance your retailer may take the old appliance for disposal.

TECHNICAL SPECIFICATION

Dimensions	Weight	
Cut-Out		
Power Supply Input 230V~ / Output 12Vdc 2A Peak Music Power 120W @ 4Ω Frequency Response 60Hz-20000KHz SNR ≥91dB	Mounting Depth	
Peak Music Power	Cut-Out	
Frequency Response	Power Supply	Input 230V~ / Output 12Vdc 2A
SNR	Peak Music Power	
	Frequency Response	60Hz-20000KHz
Rivetoeth Version 4.0	SNR	≥91dB
	Bluetooth Version	

CLEANING

- · Disconnect from the mains supply before cleaning any of the components.
- Use a dry, soft cloth only to clean the unit
- · Do not use detergents or abrasive cleaners

SERVICE WARRANTY

Electrovision guarantees the product free from defects in materials and workmanship for a period of one year.

Should this unit be operated under conditions other than those recommended, at voltages other than the voltage indicated on the unit, or any attempts made to service or modify the unit, then the warranty will be rendered void.

The product you buy may sometimes differ slightly from illustrations. This warranty is in addition to, and does not affect, your statutory rights.

Electrovision Ltd., Lancots Lane, Sutton Oak, St. Helens, Merseyside WA9 3EX

website: www.electrovision.co.uk